



Zestaw Z001

Audi, VW,
Seat, Skoda /1



numer ROMIX	ilość sztuk w zestawie	numer ROMIX	ilość sztuk w zestawie
10915	10	16035	25
10918	20	16307	20
11450	20	20509	20
11453	20	20516	25
11458	10	20517	20
11464	10	40526Z	20
11468	10	41278Z	20
12619	20	45168	20
15506	20	C10033	20

Zestaw Z001 **razem sztuk 325**



Zestaw Z002

Audi, VW,
Seat, Skoda /2



numer ROMIX	ilość sztuk w zestawie	numer ROMIX	ilość sztuk w zestawie
12620	20	A81056	20
50142Z	20	C10007	20
605064	20	C10022	20
70143Z	20	C10028	20
80101	10	C10087	10
A11888	20	C10126	10
A12271C	20	C10131	10
A12954	20	C10133	10
A14720	25	C30847	20

Zestaw Z002 **razem sztuk 315**



Zestaw Z003

Citroen, Peugeot,
Renault



numer ROMIX	ilość sztuk w zestawie	numer ROMIX	ilość sztuk w zestawie
10556	10	A20001	20
11261	20	C10010	20
11383	20	C10018	20
12409	20	C10088	25
12438	20	C10090	20
50129Z	10	C10093	20
71187	20	C10128	20
71188	20	C30141	20
A18000	20	C30142	10

Zestaw Z003 **razem sztuk 335**



Zestaw Z004 Mercedes



numer ROMIX	ilość sztuk w zestawie	numer ROMIX	ilość sztuk w zestawie
10430	20	A14294	20
12315	10	A15054	20
14202	20	A15687	10
15253	20	A15688	20
16305	20	A15689	20
45099	20	A15955	20
45168	20	A82026	20
604201	10	B23171	20
A12301S	20	C10032	20

Zestaw Z004 razem sztuk 330



Zestaw Z005 wkrety montażowe



numer ROMIX	ilość sztuk w zestawie	numer ROMIX	ilość sztuk w zestawie
40506Z	25	C10022	20
40523Z	20	C60158	100
40526Z	20	C60159	100
45087	20	C60160	100
45099	20	C60161	100
45168	20	C60162	100
45188	20	C60163	100
45193	20	C60164	20
45195	20	C60165	20

Zestaw Z005 razem sztuk 845



Zestaw Z006 Fiat, Afa Romeo Lancia



numer ROMIX	ilość sztuk w zestawie	numer ROMIX	ilość sztuk w zestawie
10050	25	11027	20
10060	20	11028	20
10093	25	11152	20
10131	20	12438	20
10183	20	15028	20
10320	20	20242	20
10402	20	C10049	25
10404	20	C10093	20
11012	25	C30179	20

Zestaw Z006 razem sztuk 380



Zestaw 2007 FORD



numer ROMIX	ilość sztuk w zestawie	numer ROMIX	ilość sztuk w zestawie
11460	20	A14424	25
15253	20	A14545C	25
16309	20	A14545S	25
45168	20	A15749	20
55107Z	20	A16178	20
58211Z	20	A81113	20
60117	10	A82020	20
60120	10	B23171	20
60121	10	C30847	20

Zestaw 2007 razem sztuk 345



Zestaw 2008 marki japońskie i koreańskie /1



numer ROMIX	ilość sztuk w zestawie	numer ROMIX	ilość sztuk w zestawie
60001	20	B17267	20
71177	10	B18877	20
80106	10	B19145	20
A175047	20	B19233	10
A175047C	20	B19239	20
B14696	20	B19257	20
B14992	20	B21001	20
B16858	20	B21002	20
B17216	10	B21005	20

Zestaw 2008 razem sztuk 320



Zestaw 2009 marki japońskie i koreańskie /2



numer ROMIX	ilość sztuk w zestawie	numer ROMIX	ilość sztuk w zestawie
B21003	20	B22628	20
B22048	10	B22635	20
B22049	10	B23143	20
B22063	10	B23144	20
B22088	20	B23145	20
B22089	20	C10070	20
B22090	20	C10075	20
B22125	10	C10076	20
B22146	20	C10077	20

Zestaw 2009 razem sztuk 320



Zestaw Z010

Opel, Daewoo, Chevrolet



numer ROMIX	ilość sztuk w zestawie	numer ROMIX	ilość sztuk w zestawie
10495	20	60003	20
10513	20	603011	20
15253	20	A12301S	20
40526Z	20	A13011	25
41278Z	20	A14208	20
45168	20	C10005	20
50270Z	20	C10008	20
60001	20	C10009	20
60002	20	C50550	20

Zestaw Z010 **razem sztuk 365**



Zestaw Z011

BMW, Volvo



numer ROMIX	ilość sztuk w zestawie	numer ROMIX	ilość sztuk w zestawie
55130T	20	C10006	20
605064	20	C10019	10
A13011	25	C10032	20
A14929	20	C10110	5
A17489	10	C10135	10
A82028	20	C30056	20
B21111	10	C30961	20
B21124	20	C50354	10
C10005	20	C50493	10

Zestaw Z011 **razem sztuk 290**



Zestaw Z012

blaszki montażowe i specjalistyczne



numer ROMIX	ilość sztuk w zestawie	numer ROMIX	ilość sztuk w zestawie
12623	50	16044	30
14202	20	16100	20
16031	50	16151	20
16033	50	16307	30
16034	50	16308	20
16035	50	16309	20
16036	50	70143Z	20
16037	30	A14208	20
16043	50	A16419	20

Zestaw Z005 **razem sztuk 600**